

L-Body rear Sway Bar

This is a way to keep your stock sway bar while adding the PolyBushings sway bar.



Figure 1

Step 1

Bolt the sway bar to rear axle with the end links as shown in fig.1

The end link holes are there from the factory. If they are not there, you will need to mark and drill the holes. Center the bar as shown in fig. 1.



Figure 2

Step 2

Add the bushings, brackets and spacers as shown in fig. 2

Use these as a template to mark where you need to drill the holes as shown in fig. 3

Step 3

Move the bracket out of the way and drill the 3/8" holes for the bracket as shown in fig. 4



Figure 3

Step 4

Lube the bushings and put them on the sway bar. Attach the bracket, flat plate and round spacers with the 3/8"x 2-1/2" bolts as shown in fig.5 & 6.

Step 5

Tighten the endlinks, then tighten the swaybar bushing brackets.



Figure 4



Figure 5



Figure 6